

# Quick Start Assembly/Install Instructions

## CLEARSTREAM™ J-Mount

**Before attaching the antenna to any surface, TEST RECEPTION in that area.**

Connect the antenna to the TV or receiver and run a full channel scan.  
If reception is not as desired, move the antenna and rescan TV/receiver.

Tools Required: Power Drill, 3/16" Drill Bit,  
8 and 10mm Ratcheting Drivers, Medium-sized Cross Point Screwdriver.  
Before beginning assembly, make sure all pieces needed are present.

A		1/4" x 50mm Mounting Bolt	4
B		1/4" Hex Nut	2
C		1/4" x 40mm	2
D		Roof Sealing Pads	4

