CLEARSTREAM MICRON™

Before attaching the antenna to any surface, TEST RECEPTION in that area.

Connect the antenna to the TV or receiver and run a full channel scan. If reception is not as desired, move the antenna and rescan TV/receiver.



The ClearStream Micron Indoor Antenna comes with:

- 1 Antenna
- 2 Stand mounting bracket
- 3 Flush mounting bracket
- 4 Mounting hardware

Table Top Use:



1. Place antenna into base as shown in Fig.1.




- 2. Tabs in base will fit into grooves on back plate of antenna. Fig.2.
- 3. Connect cable to TV or receiver.
- 4. Perform channel scan on TV or receiver tuner. Refer to your TV / receiver owners manual for instructions.
- 5. If reception is not as desired move antenna and rescan the TV or the receiver.

Flush Wall Mount:

- 1. Remove insert from base at center holes. Fig 3 3a.
- 2. Use insert as a template to mark center mounting holes on wall. Screw hanging screws into wall and back out far enough to allow insert to attach to wall.
- 3. To attach insert to antenna, screw short screws provided into the back of the antenna using 2nd holes from top and bottom. Fig 4.







- 4. Hang antenna on the wall. 5. Connect cable to TV or receiver.
- 6. Perform channel scan TV or receiver tuner. Refer to your TV/receivers owners manual for more instructions.

Raised Wall Mount:



- 1. Remove insert from base at center holes. Fig 3- 3a. above.
- 2. Use insert as a template to mark center mounting holes on the wall.
- Screw hanging screws into the wall and back out far enough to allow insert to attach to wall.
- 4. Reattach insert to base.
- 5. To attach insert to antenna, screw long screws provided into back of antenna using 2nd holes from top and bottom. Fig. 5.
- 6. Hang antenna on the wall.
- 7. Connect cable to TV or reciever.
- 8. Perform channel scan. Refer to your TV/receivers owners manual for more instructions.

Call Our HELP LINE at 877-825-5572

One of our specialists can talk you through any problems you may have.