

Quick Start Assembly/Install Instructions

CLEARSTREAM™ Micron™ Reflector

Before attaching an antenna to any surface, TEST RECEPTION in that area.

Connect the antenna to the TV or receiver and run a full channel scan.
If reception is not as desired, move the antenna and rescan TV/receiver.

Tools Required: Cross point screwdriver.




Before beginning assembly, make sure all pieces needed are present.



ATTACHING REFLECTOR TO THE MICRON ANTENNA:

1 Remove the Micron Antenna insert from base at center holes. Fig 1 - 1a.

2 Lay U-bracket into mounting base with hooks pointing downward. Place base insert on top as shown in Fig. 2.






3 Attach components together with reflector base screws (use the inside holes) provided as shown in Fig. 3. Small screws fit into the larger screws.

4 Place completed base on flat surface. Fig. 4.

Slide the Micron onto it's base:

5 Place antenna into base as shown in Fig.5.

6 Tabs in base will fit into grooves on back plate of antenna. Fig.5a.



Attach Reflector:

7 Slide reflector down onto U-bracket as shown in Fig. 6. Reflector is properly attached **8** Connect cable to TV or receiver.

Change TV input to "Antenna" or "Air" and then perform channel scan. Refer to your TV/receiver owners manual for instructions.

If reception is not as desired move antenna and rescan the TV or the receiver.

Call Our HELPLINE at 877-825-5572

One of our specialists can talk you through any problems you may have.