


Quick Start Assembly/Installation Instructions

CLEARSTREAM VIEW™ AMPLIFIED


Connect the antenna to the TV or converter box and run a full channel scan. If reception is not as desired, move the antenna and rescan for the available channels.

Before beginning assembly, make sure all parts needed are present.

Before attaching the antenna to any surface, TEST RECEPTION in that area.



- The ClearStream VIEW comes with:
- 1) ClearStream VIEW Antenna
 - 2) 12 ft. Coaxial Cable
 - 3) 20dB In-Line Amplifier
 - 4) 3 ft. Coaxial Cable for In-Line Amplifier
 - 5) USB Power Adapter
 - 6) 5 ft. USB Cable



With easy-to-use slide locks, you can add or change your photos in a snap! Pull each slide lock to remove the back panel and add your photos, and then push the slide locks back into place when you're done. The HDTV antenna element is integrated into the back panel. Do not modify, tear, or remove the covering as this may cause interference with broadcast TV reception.

Use the keyhole on the back to install the antenna on a wall.



In some areas, broadcast signals are strong enough that an amplifier is not necessary. Connect the antenna to the TV/converter box without the amplifier first; if reception is not as desired, follow the instructions below to install the antenna with the In-Line Amplifier.




Back of Antenna Frame

1. Connect one end of the 12 ft. Coaxial Cable (2) to the connector on the back of the antenna (1) and the other end of the Coaxial Cable (2) to the "Antenna Input" on the TV/converter box.
2. Follow the instructions in the owner's manual of your TV or converter box to change the input from 'CABLE' to 'ANTENNA', 'AIR', or 'BROADCAST'.
3. Check reception by scanning for channels on your TV/converter box. If reception is not as desired, reposition or relocate the antenna and rescan the TV for channels. If reception is still not as desired, install the In-Line Amplifier (3) by following the instructions below.

Helpful Tips: When using the USB port on your TV, the in-line amplifier will only draw power when the TV is turned on, eliminating power consumption. If you do not have a USB port on the back of your TV, use the provided USB power adapter with any standard AC wall outlet.

INSTALLATION WITH IN-LINE AMPLIFIER

1. Connect one end of the Coaxial Cable (2) to the antenna (1) and then connect the other end of the Coaxial Cable (2) from the antenna onto the "TO ANT" connector on the In-Line Amplifier (3).
2. Connect the provided 3 ft. Coaxial Cable (4) into the In-Line Amplifier (3) connector labeled "TO TV", and connect the opposite end into the "Antenna Input" on your TV/converter box.
3. Connect the USB Cable (6) into the In-Line Amplifier (3). You have the option to connect the cable into a USB port on your TV for power, or use the USB Power Adapter (5) and then plug the adapter into a power outlet. Verify the blue LED light is on.
4. Perform a channel scan on your TV/converter box.



Helpful Tips: Be ready to experiment with various locations in your home. The best option is usually on a wall facing the broadcast towers. Remember to rescan for channels in every location. Use a longer cable, if necessary, to extend the provided coaxial cable. You can purchase extra cable and a coaxial coupler to connect the two cables at your local hardware store.



Call to Learn.
Toll-Free Helpline: **1-877-825-5572**

Technical Assistance is available Monday – Friday, 9:00 am to 9:00 pm and Saturday – Sunday, 10:00 am to 6:00 pm, Central Time.



To locate the broadcast towers in your area, go to antennapoint.com and enter your zip code, scan the QR code, or download the free Antenna Point app to your Android/iOS smartphone or tablet.

TROUBLESHOOTING:

Problem: I'm not getting any signals at all.

Possible causes:

1. Analog-only televisions (manufactured before 2007) need a digital converter box. You MUST perform a channel scan on the converter box.
2. A digital TV must be programmed in order to receive digital channels. Refer to your TV owner's manual for instructions.
 - a) Your TV must be set to the proper input source. Press the input button on your remote and make sure the input is set to TV.
 - b) Select the menu or home button on your remote and set the signal type to "Antenna", "Air", or "Broadcast".
 - c) Within the TV's Setup menu, select "Channel" or "Channel scan" to scan for the available channels.
3. Make sure the antenna is facing the broadcast tower locations serving your area. Visit www.antennapoint.com for more information on broadcasters and tower locations serving your area, or download the free Antenna Point app to your Android/iOS smartphone or tablet.
4. You do not have a clear line of sight to your local broadcast towers. You might need to elevate and/or move your antenna. Remember to rescan for channels in every location.
5. You are outside the range of your antenna's capabilities. Depending upon the distance between your home and the local broadcast towers, you may need a long range outdoor/attic antenna. Antennas Direct offers many models for this purpose.

6. You may have loose coaxial cable connections.

Check ALL connections for a tight fit.

7. Building materials such as brick, metal siding, radiant barrier, or stucco can greatly reduce the incoming signal. Move your antenna to a wall facing the broadcast towers and rescan for the available channels.

Problem: I'm receiving every channel except for one.

Possible cause:

1. You may need to rescan the TV tuner or converter box. The channel you are not receiving may have its transmitter lower on the broadcast tower than the other transmitters and your line of sight is obstructed. Try elevating the antenna or moving it to another location. Repeat as needed.

Problem: I'm having signal breakups, but I'm only two miles from the broadcast tower.


Possible cause:

1. Your TV may be receiving interfering signals. A larger/stronger antenna will not necessarily solve this problem. Consider moving the antenna, making sure it is not placed near metal objects or other antennas. If this is not successful, your signal may be too strong and may require the use of an attenuator. Call our helpline or chat with us online at antennasdirect.com for an analysis of your area and installation. We may be able to offer simple solutions.

Before You Return, Call to Learn.



For Tower Locations:
antennapoint.com



Input on Antenna Mode



Scanning is a Must
When in Doubt, Rescan

HELPLINE: 1-877-825-5572

MODEL # VIEW

Amplifier Regulatory Notice: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the antenna.
2. Increase the separation between the equipment and converter box.
3. Connect the equipment into an outlet on a different circuit from which the converter box is connected.

Antennas Direct® Inc.
Lifetime Warranty

Antennas Direct® Inc. warrants this product against any defects in materials or workmanship for as long as you own the product. No warranty claim will be honored unless, at the time the claim is made, you present proof of purchase from an authorized Antennas Direct® Inc. dealer.

Antennas Direct® Inc. will either repair or replace the defective product at no charge to you. This warranty covers parts, but does not cover any costs incurred in the removal or reinstallation of the product. This limited warranty does not apply if the product is damaged or fails due to: misuse, improper installation, abuse, and modification of the product as originally manufactured by Antennas Direct.

Antennas Direct® Inc. will not assume any liabilities for any other warranties, expressed or implied by any other person. The foregoing shall be the sole and exclusive remedy of any person, whether in contract, tort, or otherwise, and Antennas Direct® Inc. shall not be liable for incidental or consequential damage or commercial loss, or for any other loss or damage, as set forth above.

16388 Westwoods Business Park, Ellisville, MO 63021, USA

©Antennas Direct
Model # VIEW
08.2018



Call to Learn.
Toll-Free Helpline: **1-877-825-5572**

Technical Assistance is available Monday – Friday, 9:00 am to 9:00 pm
and Saturday – Sunday, 10:00 am to 6:00 pm, Central Time.